
MICROLINE 280

MAINTENANCE MANUAL

PREFACE

This document describes field maintenance procedures for the Microline 280 printer. It is intended for field maintenance personnel.

TABLE OF CONTENTS

	Page
1. CONFIGURATION	1 - 1
1.1 Standard Printer Configuration	1 - 1
1.2 Options	1 - 2
2. INSTALLATION PROCEDURE	2 - 1
2.1 Unpacking	2 - 1
2.1.1 Unpacking the Packing Box	2 - 1
2.1.2 Unpacking the Printer Unit	2 - 2
2.1.3 Unpacking the Accessories	2 - 3
2.2 Installation	2 - 4
2.2.1 Precautions for Installation	2 - 4
2.2.2 Removing the Shipping Retainer	2 - 6
2.2.3 Installation of the Accessories	2 - 6
2.2.4 Connecting Cables	2 - 9
2.2.5 Installing Paper	2 - 10
2.2.6 Powering On	2 - 10
3. THEORY OF OPERATION	3 - 1
3.1 Electrical Operation	3 - 1
3.1.1 General	3 - 1
3.1.2 Microprocessor and Its Peripherals Circuits	3 - 3
3.1.3 Initialization	3 - 5
3.1.4 Interface Control	3 - 6
3.1.5 Printhead Drive Circuit	3 - 7
3.1.6 Spacing Drive Circuit	3 - 8
3.1.7 Line Feed Circuit	3 - 10
3.1.8 Alarm Circuits	3 - 11
3.1.9 Paper End Detection Circuit	3 - 12
3.1.10 Power Supply	3 - 13
3.2 Mechanical Operation	3 - 14
3.2.1 The Printhead Mechanism and Its Operation	3 - 14
3.2.2 Spacing Mechanism and Operation	3 - 16
3.2.3 Head-Gap Adjusting Mechanism	3 - 18
3.2.4 Ribbon Feed Mechanism and Operation	3 - 20
3.2.5 Paper Feed Mechanism and Operation	3 - 22
3.2.6 Paper-End Detection Mechanism	3 - 26
3.2.7 Semi-Automatic Sheet Feed (SASF) Mechanism and Function	3 - 28

4.	ASSEMBLY/DISASSEMBLY	4 - 1
4.1	Precautions for Parts Replacement	4 - 1
4.2	Maintenance Tools	4 - 2
4.3	Disassembly/Reassembly of Procedure	4 - 3
4.3.1	Print Head	4 - 5
4.3.2	Upper Cover	4 - 7
4.3.3	Control Board	4 - 11
4.3.4	Transformer Assembly	4 - 13
4.3.5	Power Supply Board	4 - 15
4.3.6	Operation Board	4 - 16
4.3.7	Printer Mechanism	4 - 17
4.3.8	LF Motor Assembly	4 - 19
4.3.9	Connection Board	4 - 21
4.3.10	Ribbon Feed-gear Assembly	4 - 23
4.3.11	Space Motor Assembly	4 - 25
4.3.12	Space Rack	4 - 27
4.3.13	Carriage Cable	4 - 29
4.3.14	Carriage Frame	4 - 31
4.3.15	Column Indicator Bar	4 - 33
4.3.16	Platen Assembly	4 - 35
4.3.17	Paper-chute Assembly	4 - 37
4.3.18	Bottom Paper Guide Assembly	4 - 38
4.3.19	Near-end Lever and Bracket	4 - 39
4.3.20	Bottom Near-end Lever	4 - 40
4.3.21	Switch Assembly	4 - 41
4.3.22	Pin Tractor Assemblies (R and L)(Optional Tractor Unit)	4 - 42
5.	ADJUSTMENT	5 - 1
5.1	Head-Gap Adjustment	5 - 1
5.2	Space Rack and Roller-Gap Adjustment	5 - 3
6.	CLEANING AND LUBRICATION	6 - 1
6.1	Cleaning	6 - 1
6.2	Lubrication	6 - 2
7.	TROUBLESHOOTING AND REPAIR	7 - 1
7.1	Items to Check Before Repair	7 - 1
7.2	Finding the Cause of Error	7 - 1
7.3	Troubleshooting	7 - 6
APPENDIX A	PCB LAYOUT	A - 1
APPENDIX B	CIRCUIT SYMBOLS AND CIRCUIT DIAGRAMS	B - 1
APPENDIX C	SPARE PARTS LIST	C - 1

1. CONFIGURATION

1. CONFIGURATION

1.1 Standard Printer Configuration

The standard configuration of the ML280 is as follows:






Figure 1-1. Printer Configuration

1.2 Options


- (1) Tractor unit (consists of Pin tractor assy, acoustic cover, and access cover)



Pin tractor assembly




Acoustic cover




Access cover


- (2) Roll paper stand




(3) Super-speed RS232-C serial interface board



(4) Super-speed RS422-A serial interface board



(5) Automatic Cut-Sheet Feeder (C.S.F.)




2. INSTALLATION PROCEDURE

2. INSTALLATION PROCEDURE

2.1 Unpacking


2.1.1 Unpacking the Packing Box

- (1) Open the packing box.
- (2) Remove the printer and the paper separator with the cushioning materials from the packing box.
- (3) Peel the fixing tape off and remove the paper separator.
- (4) Remove the cushioning material A, B and the cushioning sheet.
- (5) Peel off the fixing tape off the packaging box and remove the accessories.
- (6) Peel off the fixing tape off the packaging box and remove the user's manual.




2.1.2 Unpacking the Printer Unit

- (1) Take out the printer from the plastic bag.
- (2) Remove the desiccant and the caution sheet along with the fixing tape.
- (3) Remove the fixing tape from the access cover.



2.1.3 Unpacking the Accessories

- (1) Take out the AC power cord, the ribbon cassette from the plastic bag.
- (2) Take out the user's manual from the plastic bag.




2.2 Installation (For details, refer to the Setup Guide.)


2.2.1 Precautions for Installation

When installing the printer, observe the following precautions:

- (1) Do not install the printer in the following places:
 - a) Place exposed to direct sunlight
 - b) Place with great fluctuations in temperature
 - c) Place exposed to outdoor wind
 - d) Dusty place
 - e) Near a door
 - f) Too near an air conditioner
 - g) Place subject to heavy vibrations
- (2) Adjust the temperature and humidity of the installation site as follows:
Temperature: 41°F to 104°F (5°C to 40°C)
Humidity: 20%RH to 90%RH
- (3) To install the printer and printing paper, observe the following procedure:
 - a) Adjust the height of the desk on which to place the printer to 30 inches (75 cm) as a standard. (See to it that the desk surface is horizontal and smooth and that the rubber protectors on the bottom of the desk legs are level.)
 - b) Set the printing paper on the floor below the printer so that it may be fed into the printer without skewing from the feeding path by more than 2 inches (5 cm).




- c) Align the rear section of the printer with the rear edge of the desk. Keep a distance of 24 inches (60 cm) or more between the rear section of the printer unit and the wall to provide a space for printed paper being fed out.
- d) Keep a distance of 4 to 6 inches (10 to 15 cm) or more between the unprinted paper fed into the printer and the printed paper fed out of the printer. If the paper going in one direction interferes with the paper going the other way, they may jam inside the printer.



2.2.2 Removing the Shipping Retainer


Remove the shipping retainer that secures the printhead.




2.2.3 Installation of the accessories

(1) Ribbon cartridge

① Remove the wrapper of the ribbon cartridge.




- ② Before setting, turn the take-up knob to tighten the ribbon.
- ③ Push the rear of the cartridge down first. Make sure it snaps into the boss.




Important: Do not peel off the plastic film on the top of the cartridge. It is a part of the cartridge.

- ④ Lower the front of the cartridge over the printhead.




- ⑤ Make sure that the ribbon cartridge is fitted correctly.




- ⑥ Grasp the cartridge on both sides, making sure the take-up knob revolves in the direction of the arrow icon.

Note: When passing the ribbon between the printhead and the platen, make sure that the ribbon is not twisted or bent and that the left/right arms of the cartridge fit correctly.

Inserting the Ribbon Cartridge [a side view]




- (2) Paper separator
Install the paper separator by placing its hooks in the slots provided in the upper cover.




2.2.4 Connecting Cables

- (1) Connect the interface cable to the printer.
If your interface has a pressure connection terminal for grounding, connect the terminal in the chassis ground connector by using a suitable screw.




- (2) Connect the AC cable to the printer.




2.2.5 Installing Paper

Install printing paper on the printer for the test run.



2.2.6 Powering On

- (1) Turn on the POWER switch on the right side of the printer unit.
- (2) Confirm that the POWER LED is on and that the printhead returns to its home (left most) position.



- (3) If the printer unit shows no abnormality after it is powered on, proceed to the next step (4) for test printing.

(4) Test printing

- After confirming that the POWER switch is off, turn it on while pressing the LINE FEED and SELECT switch.
- Confirm that the printer unit prints out the test pattern as shown in the figure below.
- Press the SELECT switch to end the printing test.
- Confirm that the SELECT lamp is on, indicating that the printer unit is ready to receive printing data from the host computer.

```
l' '#S&6'()'+,-./0123456789; ;<->?@ABC----G'()*+,-./0123456789; ;<->?@ABCDEFGH  
1' '#S&6'()'+,-./0123456789; ;<->?@ABCD  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDE  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEF  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFG  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGH  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHI  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJ  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJK  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKL  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLM  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMN  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNO  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOP  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQ  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQR  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRS  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRST  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTU  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUV  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUVH  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUVHX  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUVHXY  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUVHXYZ  
' '#S&6'()'+,-./0123456789; ;<->?@ABCDEFGHIJKLMNOPQRSTUVHXYZ[
```

3. THEORY OF OPERATION

3. THEORY OF OPERATION

3.1 Electrical Operation

This section describes the operation of the printer circuits.

3.1.1 General

The electrical section of the printer consists of the components shown in figure 1.

In addition to the microprocessor, the control board also contains a DC power circuit, drive circuits, a paper-end sensor, and an interface connector.

The power supply connects with the control circuit board via a cable, and other electrical parts connect via the connection board.




Figure 1. Configuration of Electrical Section

3.1.2 Microprocessor and Its Peripheral Circuits

(1) Microprocessor (Q12: 80C154)

The microprocessor is the nucleus of the control circuit, and its peripheral circuits operate under control of this microprocessor.

The I/O ports of the microprocessor are connected with the address bus, data bus, and control lines.

(2) Program ROM (Q8)

The program ROM stores the control program for the printer. The microprocessor operates under control of this program.

(3) RAM (Q13)

The RAM stores data such as received print data.

(4) LSI (MSM6990)

The MSM6990 is an external interface and motor control LSI. It has the following functions:

A: External interface controller

(a) Parallel interface function

The parallel interface function mode is selected when the level of the mode selection signal (ISEL) is high. In this mode, IFD1 to 8 are used as an input port; the parallel data received through the interface connectors is latched in synchronization with the strobe signal ($\overline{STB}$) and is sent to the CPU in synchronization with the RD signal. In this mode, the MSM6990 also sends $\overline{BUSY}$, $\overline{ACK}$, $\overline{PE}$ and $\overline{SELECT}$ signals to the interface connector in synchronization with the WR signal.

(b) Address decoder

The address decoder decodes the address signal (A12 to A15), and sends out the RAM (Q13) chip select signal ($\overline{S RAM SEL}$).

(c) Parallel port function

This function is used to load the DIP switch data.

B: Motor controller

(d) Space speed control function

This function accelerates and decelerates the space motor in accordance with commands from the microprocessor and controls the space motor speed in each printing mode.

(e) Dot timing generation function

This function generates the dot-on timing signal ($\overline{IPT}$), synchronized with the printing speed in accordance with output signals (PHASE A, B) of the encoder on the space motor, and sends this timing information to the microprocessor.

(f) I/O ports

The MSM6990 has a 12-bit output port and a 10-bit input port. It outputs control signals in accordance with the commands input from the microprocessor.

The input port is also used to read information from the operation panel switches, etc.

(g) Address latch

The address latch latches the low-order 8 bits of the address (A0 to A7). These bits are used as an address for read/write operations with peripheral devices.

3.1.3 Initialization

The printer is initialized when the power is turned on or when the parallel interface signal I-PRIME is received from the host computer.

Initialization is started by resetting Q12 (microprocessor) and Q4 (interface LSI) with the RST OUT signal output from the reset circuit (Q7 pin 13).

A program then starts and sets microprocessor(Q12) and LSI (Q4) modes, checks memory (ROM and RAM), initializes the RAM, and moves the carriage to home. Next, the program establishes the interface signals (output ACK and BUSY signals), turns on the SELECT indicator, and informs the host computer that the printer is ready to receive data, thus completing the initialization.


3.1.4 Interface Control

(1) Parallel interface

The data from the interface is input through the connector (CN1), and the interface LSI (Q4: MS6990) latches this input data in synchronization with the STB signal.

The BUSY signal is on while processing this data. After processing, the BUSY signal is turned off and an ACK signal is sent to request the next data.

The BUSY signal is also sent to stop data sending when the receive buffer is full.




3.1.5 Print Head Drive Circuit

This circuit drives the head magnets corresponding to the HEAD DATA1 to 9 signals in synchronization with the HEAD-ON signal, thus making the print head print characters.

When the HEAD-ON signal goes high, the RC integrator (R548 and C5) determines the head drive time. This integrator adjusts the printing pressure automatically to compensate for variations in the drive voltage (+30 V).

That is, the integrator increases the drive time if the drive voltage drops and decreases the drive time if the drive voltage rises.



3.1.6 Spacing Drive Circuit


(1) Space motor control

The motor control LSI (Q4: MSM6990) outputs the space motor phase signals (SPU, SPV, and SPW) in accordance with the spacing command from the microprocessor. At the same time, it outputs the overdrive signal (SPD-A).

The SPD-A signal is a fixed-period pulse signal whose pulse width is controllable by program. It is used to control the motor drive time.

The SP ON/OFF signal is output during acceleration and deceleration, which requires a large amount of torques.


The motor driver (MTDV) drives the space motor in accordance with these signals. Pins 9 and 11 of the MTDV are for the overvoltage and overcurrent protective circuits respectively.



(2) Slit encoder

PHASE-A and PHASE-B signals are generated by the photosensor and circular slit when the space motor rotates.


The motor control LSI (Q4: MSM6990) frequency divides these edge pulse signals in accordance with the print pitch and outputs the IPT signal to provide dot-on timing and carriage position detection timing.



3.1.7 Line Feed Circuit

The line feed motor is locked at +8 V when it is not turning.

During line feed, the line feed motor is driven by the +30 V level applied in accordance with the LF OVD signal.



3.1.8 Alarm Circuits

(1) Drive circuit error alarm

This circuit protects the print head drive circuit, space motor drive circuit, line feed motor drive circuit, and peripheral circuits by blowing a fuse when an error occurs.

The circuit monitors the drive time using the HDALM, SPALM, and LFALM signals interlocked with the overdrive signal of each drive circuit. If the drive time of any drive circuit exceeds the specified time, the drive circuit fault alarm circuit outputs an ALM signal (high) to turn on the SCR.

This short-circuits the secondary coil (30 V) of the transformer, resulting in an overcurrent in the primary coil, and blows the AC fuse.

(2) Head overheat alarm circuit

In order to protect the head coils, this circuit monitors the head temperature using the thermistor built into the print head.

If printing is performed continuously for an extended period, the print head gets hot. When the head temperature reaches a certain value (approximately 100 degrees C), a head overheat alarm is detected.

When this alarm is detected, printing stops temporarily to wait for the head to cool. When the head temperature drops below the alarm detection temperature, printing resumes.

Alarm detection is performed as follows:

When the temperature in the print head rises, the resistance of the thermistor decreases, and the potential of the comparator (Q7) negative input decreases to invert the comparator output, causing the HEAD TEMP signal to be output to the motor control LSI.

3.1.9 Paper End Detection Circuit

When the paper runs out, the photosensor (PE) on the control board turns off, and as a result, the PAPER END signal goes to 0. This signal is fed to pin 55 of the motor control LSI (Q4), stopping the printing operation and lighting the ALARM indicator.

3.1.10 Power Supply

The power supply consists of a power transformer, power supply board, and a DC power supply circuit.

The input AC voltage is transformed into 7.6 VAC, 24 VAC, and 10 VAC by the power transformer, and these AC voltages are further converted to +8 VDC, +5 VDC, and +30 VDC by the DC power supply circuit and supplied to each circuit.

(1) **Power supply board**

The power supply board contains the power switch, AC fuse, and the AC noise filter.

(2) **Power transformer**

If the power transformer temperature rises abnormally, the built-in temperature fuse of the transformer blows to prevent any adverse effect on other components.

3.2 Mechanical Operation

3.2.1 The Printhead Mechanism and Its Operation (see figure 3)

The print head is spring-loaded, utilizing a permanent magnet, and can be easily removed or installed. The print head is mounted on a carriage that runs parallel to the platen and is connected with the control circuit via the head board.

The print head consists of:

- (a) Wire guide
- (b) Print wires
- (c) Armature assembly
- (d) Yoke
- (e) Springs
- (f) Spacer
- (g) Magnet assembly
- (h) Thermistor
- (i) Printed-circuit board

(1) Print head operation

When the print head is in the non-printing state, each armature is attracted by the permanent magnet, and the springs holding the armatures are compressed by the thickness of the spacer. The print wires, which are fastened to the individual armatures, are therefore held retracted within the wire guide.

When signals corresponding to a character to be printed are detected by the control circuit, currents flow through the corresponding coils to nullify the magnetic flux generated by the permanent magnet between the armatures corresponding to those coils and the permanent magnet pole. As a result, those armatures are driven toward the platen by the force of the armature springs, and the print wires fastened to those armatures eject from the tip of the wire guide and strike the paper through the ribbon to print dots on the paper.

After the character is printed, the magnetic flux of the permanent magnet attracts the armatures again so that the print wires retract into the wire guide.

The print head has a built-in thermistor to prevent the coils from overheating and burning due to continuous bi-directional printing over a long period. If the coil temperature exceeds the limit (approximately 100 degrees C), the control circuit detects the thermistor signal and stops the printing operation until the coil temperature drops below the limit.




Figure 3

3.2.2 Spacing Mechanism and Operation (see figure 4)

The spacing operation is performed by driving the carriage frame, which is guided by the carriage shaft mounted parallel to the platen, with the DC motor mounted on the bottom of the carriage frame.

The space mechanism consists of:

- (a) DC motor with motor gear
- (b) Carriage frame (including stator yoke and motor board)
- (c) Carriage shaft
- (d) Space rack
- (e) Slit sensor
- (f) Slit disk

(1) Spacing operation

The carriage, with the print head and space motor mounted on it, moves parallel to the platen along the carriage shaft. As the space motor rotates counterclockwise, the motor gear is driven rightward along the space rack, and as a result, the carriage is also driven rightward.

The spacing mechanism is so designed that the carriage frame moves 0.8 inch (20.56 mm) when the space motor rotates once.

The motor also rotates the slit disk, and the slit passes through the slit sensor. The position of the carriage frame can be obtained by counting the number of slits detected by the slit sensor.




Figure 4

3.2.3 Head-Gap Adjusting Mechanism (see figure 5)

The head-gap adjusting mechanism adjusts the gap between the platen and print head by changing the tilt angle of the carriage frame with the adjusting lever.

When the adjusting lever is operated, the adjusting screw, which is interlocked with the lever via a gear, rotates to change the tilt angle of the carriage frame around the carriage shaft.

The print head, mounted vertically opposite the adjusting screw on the carriage frame, moves toward or away from the platen with change in the carriage frame tilt angle.




Figure 5

3.2.4 Ribbon Feed Mechanism and Operation (see figure 6)

The ribbon feed mechanism feeds the ribbon in synchronization with the spacing operation. The mechanism is driven by the space motor.

The ribbon feed mechanism consists of:

- (a) Ribbon feed gear assembly
- (b) Ribbon gear (space motor)
- (c) Ribbon cartridge

(1) Ribbon cartridge

A one-way-feed endless ribbon is used. Ink is replenished by the built-in ink tank in the ribbon cartridge so that clear printing is always assured.

(2) Ribbon feed operation

As the space motor rotates, the ribbon gear on the space motor shaft rotates to drive the drive gear in the ribbon cartridge via the ribbon feed gear assembly, thus feeding the ribbon.

In bi-directional printing, the ribbon gear rotational direction reverses every time the carriage movement reverses. In this case, the gears in the ribbon feed gear assembly switch the rotational direction so as to feed the ribbon in a fixed direction.




Figure 6

3.2.5 Paper Feed Mechanism and Operation


Paper feed is performed by rotating the platen and pin tractors, which are driven by the LF pulse motor.

The paper feed mechanism consists of:


- (a) Pulse motor with gear
 - (b) Reduction gear
 - (c) Platen
 - (d) Tractor feed unit
 - (e) Pressure roller
- (1) Paper feed operation (see figure 7)

The paper feed pulse motor is mounted on the left side frame. Its rotation is transmitted to the platen through the reduction gear. Platen rotation is also transmitted through the idle gear to the tractor feed unit.

The paper feed mechanism is so designed that when the pulse motor rotates 48 steps (360 degrees), paper is fed 0.17 inch (4.32 mm).



Tractor feed (option)



Fixed pin feed

Figure 7

(2) Paper clamp mechanism (see figure 8)

When the release lever is set to open, the release link moves backward, and the front and rear release links rotate counterclockwise. At the same time, the interlocked release shaft also rotates counterclockwise so that a gap is made between the pressure rollers and platen, allowing insertion of paper.

When the release lever is set to close, the release link moves forward, and the front and rear release links rotate clockwise. At the same time, the interlocked release shaft also rotates clockwise so that the pressure rollers are pushed against the platen by the front and rear pressure levers, allowing paper to be fed.




Figure 8

3.2.6 Paper-End Detection Mechanism (see figure 9)

(1) Rear paper feed

When paper is present in the printer, the paper prevents the near-end lever from falling into the groove of the paper-chute, and the paper-end sensor is on.

When the printer runs out of paper, the near-end lever falls into the groove of the paper-chute so that the rear part of the near-end lever turns off the paper-end sensor, and thus paper-end is detected. Paper-end is detected when the end of the remaining paper is approximately 1 inch (25.4 mm) from the printing position.

(2) Bottom paper feed

When paper is present in the printer, the paper prevents the bottom near-end lever from falling into the hole in the bottom paper guide. That is, the wedge on the bottom near-end lever pushes down the projection of the near-end lever, and the paper-end sensor is on.

When the printer runs out of paper, the tip of the bottom near-end lever falls into the hole in the bottom paper guide so that the rear part of the near-end lever turns off the paper-end sensor, and thus paper-end is detected. Paper-end is detected when the end of the remaining paper is approximately 1 inch (25.4 mm) from the printing position.




Figure 9

3.2.7 Semi-Automatic Sheet Feed (SASF) Mechanism and Function


1. Rear-feed type semi-automatic sheet feed (SASF) ML280

This mechanism has the function of automatically determining the position to start printing of the paper inserted after the paper-end indication has been made on the preceding paper, while printing is made in the single sheet mode.

Operation procedures are as described below:

- (1) Insert a paper from behind the platen when the paper-end indication has been made.
- (2) Throw the column indicator lever toward you to set it to the OPEN position, then the SASF switch is turned on.
- (3) Line-feed operation is started and the paper is fed until the paper-end indication disappears.
- (4) Subsequently the paper is fed by approx. 1.8 inches.
- (5) When restoring the column indicator lever to the original position, the paper is further fed by approx. 0.3 inch.

As the result, the first line of printing is set to the position approx. 1 inch below the paper top.




2. Semi-automatic sheet feed (SASF) used together with Sheet Insert Guide (SIG) ML280.

This mechanism has a function to automatically determine the position to start printing on the paper inserted while printing is made in the single-sheet mode.

Operation procedures are as described below.

- (1) Insert a paper from the front side along the SIG until reach the roller when the paper-end indication has been made. (The paper-end indication disappears when the paper is detected.)
- (2) Throw the column indicator lever toward you to set it to the OPEN position, then the SASF switch is turned on.
- (3) Line-feed operation is started and the paper is fed by approx. 1.1 inches.
- (4) When restoring the column indicator lever to the original position, the paper is further fed by approx. 0.3 inch.

As the result the first line of printing is set to the position approx. 1 inch below the paper top.




4. ASSEMBLY/DISASSEMBLY

4. ASSEMBLY/DISASSEMBLY

4.1 Precautions for Parts Replacement

- (1) Be sure to remove the AC cord and interface cable before disassembly or reassembly:
 - (a) Turn off the AC power switch, remove the AC input plug on the AC cord from the AC receptacle, then remove the AC cord from the inlet on the printer side.
 - (b) To reconnect the AC cord, first connect it to the inlet on the printer side, then connect the AC input plug to the AC receptacle.



- (2) Do not disassemble the printer as long as it is in good operating condition.
- (3) Be careful not to remove parts unless necessary. Disassembly should be kept to a minimum.
- (4) Use only the specified maintenance tools.
- (5) Disassemble the printer in the specified order. Otherwise, parts may be damaged.
- (6) During disassembly temporarily attach small parts, such as screws and collars, in their original places so as not to lose them.
- (7) ICs such as the microprocessor, ROM, and RAM units are easily damaged by static electricity. Do not wear gloves that are apt to produce static electricity when handling printed-circuit boards.
- (8) Do not place the printed-circuit boards directly on the printer or the floor.

4.2 Maintenance Tools

The tools in table 4-1 are necessary for replacing printed-circuit boards and parts in the field. Different tools may be necessary for other maintenance procedure.

Table 4-1 Maintenance Tools

No.	Tool	Quantity	Purpose
1	Phillips screwdriver No. 1-100	1	2- to 2.6-mm screws
2	Phillips screwdriver No. 2-200	1	3- to 5-mm screws
3	Screwdriver No. 3-100	1	
4	Cutters No. 5H	1	
5	Round Pliers No. 1	1	
6	Tension gauge	1	250 g
7	Metal rod	1	for head gap adjustment
8	Volt-ohm-milliammeter	1	
9	Thickness gauge set	1	(1) for head gap adjustment (2) for adjusting gap between space rack and roller

4.3 Disassembly/Reassembly of Procedure

This section explains the assembly replacement procedures according to the following disassembly system.

[Parts Layout]





Figure 4-1

[How to Change Parts]

This section explains how to change parts and assemblies appearing in the disassembly diagram below.




4.3.1 Print Head

- (1) Turn OFF the AC POWER switch, and remove AC cable ① from the outlet.

Caution: *Print head may be hot after printing.*

- (2) Remove access cover ② by lifting the rear edge of the cover.
- (3) Remove ribbon cartridge ③ by firmly holding both sides ④ and lifting.
- (4) Raise head clamp ④ and lift print head ⑤ straight up.
- (5) For reassembly, reverse the disassembly procedure.


Note: *Insert the print head ⑤ in connector ⑦ while pressing it against the carriage frame ⑥.*



4.3.2 Upper Cover


A) Roll paper stand/Pull tractor assembly.

- (1) Turn OFF the AC POWER switch, remove AC cable ① from the outlet, remove interface cable ②, and remove paper.
- (2) Remove the acoustic cover and paper separator (if installed).
- (3) Remove the pin tractor assembly ④ by depressing the lock lever ③ and tilting it backward (if installed).
- (4) Remove screw ⑤, holding the ground strap to the roll paper stand ⑧, and open the sheet guide ⑥.
- (5) Remove roll paper shaft ⑦ by pulling upward, then remove roll paper stand ⑧ by tilting it forward (if roll paper stand is installed).
- (6) Remove access cover ⑨ by lifting the rear edge.
- (7) Pull out platen knob ⑩.
- (8) Remove two screws ⑪.
- (9) Remove upper cover ⑫ by lifting the front and pushing it backward.
- (10) For reassembly, reverse the disassembly procedure.



B) Automatic Cut-Sheet Feeder (C.S.F.)

- (1) Turn OFF the AC POWER switch, remove AC cable ① from the outlet, remove interface cable ②, and remove paper.
- (2) Remove the acoustic cover and paper separator (if installed).
- (3) Remove connector ④ of the Cut-Sheet Feeder ③ .
- (4) Remove the grooved hooks of the Cut-Sheet Feeder ③ off the platen shafts, and remove the Cut-Sheet Feeder ③ off.
- (5) Remove access cover ⑨ by lifting the rear edge.
- (6) Pull out platen knob ⑩ .
- (7) Remove two screws ⑪ .
- (8) Remove upper cover ⑫ by lifting the front and pushing it backward.
- (9) For reassembly, reverse the disassembly procedure.




4.3.3 Control Board


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the serial interface board if installed by removing two screws located on both sides of the interface connector. Remove the interface board by lifting (if installed).
- (3) Remove transformer connector ① from the control board ④.
- (4) Remove three screws ② and two screws ③.
- (5) Remove control board ④ by lifting (see note below). Check the paper near-end lever ⑥ when removing the printed-circuit board.
- (6) For reassembly, reverse the disassembly procedure.

Notes:

1. Do not touch the terminal (contact) A of connector ⑤ directly by hand. Also make sure it is clean.
2. When attaching, make sure that paper near-end lever ⑥ is in the photosensor groove ⑦ on the control board ④.




View A



View A

4.3.4 Transformer Assembly


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove transformer connector ① from the control board.
- (3) Remove ground strap screw ②.
- (4) Remove two screws ③.
- (5) Remove transformer assembly ⑥ together with printed-circuit board ④ and AC cord receptacle ⑤ by lifting.
- (6) For reassembly, reverse the disassembly procedure.



4.3.5 Power Supply Board

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the transformer assembly (see 4.3.4).
- (3) Remove power supply board ③ from transformer ② by pulling out connection pins ①.
- (4) For reassembly, reverse the disassembly procedure.


Note: When assembling, set the power supply board ③ along guide ④ before inserting.



4.3.6 Operation Board


- (1) Remove the upper cover (see 4.3.2).
- (2) Disengage both ends ① and remove the operating panel ① by sliding upward.
- (3) Remove connector ② from the connection board.
- (4) For reassembly, reverse the disassembly procedure.

Note: Be careful not to damage the cable connecting the switch and the connector.



4.3.7 Printer Mechanism

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove connector ① that connects the control board ⑧ and transformer assembly ⑨ .
- (3) Remove ground strap screw ②.
- (4) Remove the operation board (see 4.3.6).
- (5) Remove four screws ③ and washers ④.
- (6) Remove printer mechanism ⑤.
- (7) Remove three screws ⑥, two screws ⑦, and control board ⑧.
- (8) For reassembly, reverse the disassembly procedure.




4.3.8 LF Motor Assembly

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove two screws ①.
- (4) Remove LF motor assembly ②.
- (5) For reassembly, reverse the disassembly procedure.

Notes:

1. *Do not touch the LF motor assembly ② terminal (contact) ① directly by hand or bend it. Also make sure it is clean.*
2. *When assembling, match the teeth of platen gear ④ and bias gear ⑤, then engage the gear at ⑥. (Bias gear ⑤ is offset from platen gear ④ by half the width of a tooth. Turn the bias gear half a tooth width in the direction of the arrow to align two teeth.)*
3. *When assembling the LF motor assembly ②, loosen the four screws ③ fastening the connection board and make a space between the base and connection board. Install the LF motor while pressing it against ⑧ and ⑨. Tighten the four screws ③ fastening the connection board.*
4. *After assembling, make sure that the platen gear ⑥ is correctly engaged and the platen turns smoothly.*




4.3.9 Connection Board

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove two screws ① and two screws ②.
- (4) Move the carriage to left end.
- (5) Pull out the carriage cable ④ together with the connection board ③.
- (6) Disengage two tabs ⑤, and remove cord clamp ⑥, contact rubber ⑦, and carriage cable ④.
- (7) Remove connection board ③ from circuit support ⑧.
- (8) For reassembly, reverse the disassembly procedure.

Notes:

1. Do not bend carriage cable ④.
2. Do not touch any of the terminals (contacts) ⑨ directly by hand or bend them. Also make sure they are kept clean.



4.3.10 Ribbon-feed Gear Assembly


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove ribbon cartridge ① by firmly holding sides ① and lifting.

Caution: *Print head may be hot after printing.*

- (3) Disengage the two front tabs ③ and two rear tabs ②. Then lift by inserting small flat screw-driver in the slot.
- (4) Remove ribbon feed gear assembly ④.
- (5) Remove carriage cable ⑤, cable holder ⑥, and contact pressure rubber ⑦ from ribbon feed gear assembly ④.
- (6) For reassembly, reverse the disassembly procedure.

Notes:

1. *Do not touch the carriage cable ⑤ and space motor assembly ⑧ terminal (contact) ⑧ directly by hand. Also make sure that the terminal is clean.*
2. *Make sure carriage cable ⑤ is not bent.*
3. *After installing ribbon feed gear assembly ④, check and adjust the gap between the platen and print head (see 5.1). Also, check and adjust the gap between the space rack and roller.*




4.3.11 Space Motor Assembly


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the print head (see 4.3.1).
- (3) Remove the ribbon feed gear assembly (see 4.3.10).
- (4) Remove connector ① while checking the concave surface.
- (5) Remove three screws ②.
- (6) Remove space motor assembly ③.
- (7) For reassembly, reverse the disassembly procedure.

Notes:

1. *Do not touch the space motor assembly ③ terminal (contact) ④ directly by hand. Also make sure that it is clean.*
2. *When installing space motor assembly ③, place the ⑤ side of the assembly close to carriage frame ④, and align the ⑥ side of the assembly with the corresponding side of the carriage frame. Then adjust the gap between the space rack and roller (see 5.2).*
3. *When installing slider ⑤, place the ⑦ and ⑧ parts of the slider close to space motor assembly ③.*
4. *After installing space motor assembly, check and adjust the gap between the platen and print head (see 5.1).*



Top View




4.3.12 Space Rack

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the print head (see 4.3.1).
- (3) Remove the ribbon feed gear assembly (see 4.3.10).
- (4) Remove the space motor assembly (see 4.3.11).
- (5) Remove spring ①.
- (6) Disengage tab ②.
- (7) Remove the space rack by inserting a flat screwdriver between space rack ③ and base frame ④ and gently lifting the space rack.
- (8) For reassembly, reverse the disassembly procedure.

Notes:

1. *After installing the ribbon feed gear assembly, check and adjust the gap between the platen and print head (see 5.1). Also check and adjust the gap between the space rack and roller (see 5.2).*
2. *When installing spring ①, twist the right end of the spring 90 degrees counterclockwise.*




4.3.13 Carriage Cable

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the print head (See 4.3.1).
- (3) Remove the ribbon feed gear assembly (see 4.3.10).
- (4) Remove the space motor assembly (see 4.3.11).
- (5) Remove the space rack (see 4.3.12).
- (6) Unlock the two tabs ① and remove cord clamp ②.
- (7) Remove contact rubber ③.
- (8) Remove carriage cable ④.
- (9) For reassembly, reverse the disassembly procedure.


Notes:

1. *Do not touch the carriage cable ④ and connection board ⑤ terminal (contact) ⑤ directly by hand. Also make sure it is clean.*
2. *Make sure the carriage cable ④ is not bent.*
3. *After installing the space motor assembly, check and adjust the gap between the platen and print head (see 5.1). Also check and adjust the gap between the space rack and roller (see 5.2).*




4.3.14 Carriage Frame

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove the column indicator bar (see 4.3.15).
- (4) Remove the print head (see 4.3.1).
- (5) Remove the ribbon feed gear assembly (see 4.3.10).
- (6) Remove the space motor assembly (see 4.3.11).
- (7) Remove the switch assembly (see 4.3.21).
- (8) Remove two screws on both sides ①.
- (9) Remove the carriage shaft ② together with carriage frame ③.
- (10) Remove the carriage frame ③ from carriage shaft ②.
- (11) Remove the head clamp ④.
- (12) For reassembly, reverse the disassembly procedure.



4.3.15 Column Indicator Bar

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove two springs ①
- (3) Remove two push shafts ② by squeezing the pins ④ in the direction of the arrow.
- (4) Remove column indicator bar ③.
- (5) For reassembly, reverse the disassembly procedure.




4.3.16 Platen Assembly

- (1) Remove the upper cover (see 4.3.2).
- (2) Disengage four tabs ① by gently pushing tabs from side plate ⑧ on each side.
- (3) Remove platen assembly ②.
- (4) For reassembly, reverse the disassembly procedure.


Notes:

1. *When assembling, match the teeth of platen gear ③ and bias gear ④, then engage the gear at ①. (Bias gear ④ is offset from platen gear ③ by half the width of a tooth. Turn the bias gear half a tooth width in the direction of the arrow to align two teeth.)*
2. *After assembling, make sure that the platen gear is correctly engaged and the platen turns smoothly.*




4.3.17 Paper-chute Assembly

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove the LF motor assembly (see 4.3.8).
- (4) Remove the platen assembly (see 4.3.16).
- (5) Open two tabs ① with a flat screwdriver, then remove paper lock release lever ②. (Be careful with the tabs because they are very small.)
- (6) Disengage middle release link ③ from rear release link ④, and remove rear release link ④.
- (7) Remove four screws ⑤ (two on each side).
- (8) Remove paper-chute assembly ⑥.
- (9) For reassembly, reverse the disassembly procedure.



4.3.18 Bottom Paper Guide Assembly


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove the LF motor assembly (see 4.3.8).
- (4) Remove the platen assembly (see 4.3.16).
- (5) Remove the paper-chute assembly (see 4.3.17).
- (6) Remove screw ①, then remove near-end lever assembly ②.
- (7) Close tab ③ and remove front release link ④ together with middle release link ⑤.
- (8) Remove two screws ⑥ and remove bottom paper guide assembly ⑦.
- (9) For reassembly, reverse the disassembly procedure.



4.3.19 Near-end Lever and Bracket


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove the LF motor assembly (see 4.3.8).
- (4) Remove the platen assembly (see 4.3.16).
- (5) Remove the paper-chute assembly (see 4.3.17).
- (6) Remove near-end lever ①.
- (7) For reassembly, reverse the disassembly procedure.

Note: Remove the printed-circuit board (see 4.3.3) by lifting to remove just the near-end lever.



4.3.20 Bottom Near-end Lever


- (1) Remove the upper cover (see 4.3.2).
- (2) Remove the printer mechanism. (See 4.3.7. The control board step 7 need not be removed.)
- (3) Remove the LF motor assembly (see 4.3.8).
- (4) Remove the platen assembly (see 4.3.16).
- (5) Remove the paper-chute assembly (see 4.3.17).
- (6) Remove bottom near-end lever ①.
- (7) For reassembly, reverse the disassembly procedure.



4.3.21 Switch Assembly

- (1) Remove the upper cover (see 4.3.2).
- (2) Remove screw ①.
- (3) Remove the switch assembly ② by sliding it left.
- (4) For reassembly, reverse the disassembly procedure.


Note: Do not touch the switch assembly ② terminals (contacts) ④ directly by hand or bend them. Also make sure they are kept clean.



4.3.22 Pin Tractor Assemblies (R and L) (Optional Tractor Unit)

- (1) Remove the sheet guide ①.
- (2) Remove screw ②.
- (3) Remove side frame ③.
- (4) Unlock lock lever ④, and remove left ⑥ and right ⑤ pin tractor assemblies.
- (5) For reassembly, reverse the disassembly procedure.

Note: When assembling, verify that the left and right sprockets are aligned.



5. ADJUSTMENT

5. ADJUSTMENT

5.1 Head-Gap Adjustment

- Tools:
- Thickness gauge set
 - Phillip's screwdriver No. 2-200
 - Metal rod about 0.04 inch (1 mm) in diameter and 3 inches (76 mm) long (an extended paper clip can be used)

Adjustment procedure (see figure 5-1)

- (1) Turn OFF the AC POWER switch and remove the AC plug from the AC receptacle.
- (2) Remove the access cover.
- (3) Remove the ribbon cartridge.
- (4) Set the adjusting lever to range 1.
- (5) Tilt the paper lock release lever back.
- (6) Insert a 0.019-inch (0.45-mm) thickness gauge between the platen and print head. Make sure that the thickness gauge can be smoothly inserted, although there may be slight friction. Perform this operation at both ends of the platen.
- (7) If gap adjustment is required, press down the adjusting gear with the metal rod to disengage the gear from the adjusting lever, and adjust the gap by turning the adjusting screw with a screwdriver.
- (8) After adjustment, move the adjusting lever from position 1 to 3 to 1, then check the gap between the platen and print head once more. The gap must be between 0.0165 and 0.019 inch (0.42 to 0.48 mm).






Figure 5-1. Head-Gap Adjustment

5.2 Space Rack and Roller-Gap Adjustment

- Tools:
- Thickness guage
 - Phillip's screwdriver No. 2-200
 - Tension guage, 250 g

Adjustment procedure

- (1) Turn OFF the AC POWER switch and remove the AC plug from the AC receptacle.
- (2) Remove the upper cover.
- (3) Remove the ribbon cartridge.
- (4) Insert a 0.1-mm thickness gauge between the space rack and roller. Make sure that the thickness gauge can be smoothly inserted, although there may be slight friction.
- (5) If adjustment is required, loosen the space motor screws with a screwdriver and adjust.
Note: Match side A with the corresponding carriage frame surface when attaching.
- (6) After adjustment, check the gap between the space rack and roller once more. The gap must be between 0.002 and 0.006 inch (0.05 to 0.15 mm). Also check that the carriage movement load without ribbon cartridge is 0.33 lb (150 g) or less.



6. CLEANING AND LUBRICATION

6. CLEANING AND LUBRICATION

6.1 Cleaning

Cautions:

1. *Be sure to turn OFF the AC POWER switch before cleaning.*
2. *Be careful not to let paper lint get inside the mechanism.*

The printer should be cleaned periodically as follows:

Period: Either 6 months or 300 operating hours, whichever comes first.

Required time: Approximately 10 minutes.

Tools: Dry, soft cloth (such as gauze) (and vacuum cleaner if available)

Parts to be cleaned: See table 6-1.

Table 6-1. Parts To Be Cleaned


Parts	Description
Carriage and its surroundings	Remove paper lint, dust, dirt, and ribbon lint.
Paper path	Clean platen pinch rollers with cleaning fluid.
Paper-end sensor	Remove paper lint and dust attached to the sensor.

6.2 Lubrication

This printer requires no oiling during normal operation. Oiling must be performed, however, when disassembling, reassembling, after cleaning oiled parts, and after replacing parts.

Type of grease: Albania grease #2EP (Shell Oil equivalent product) GEP
Locations: See figure below.

Note: Do not apply any grease to carriage shaft or along paper path (platen, roller, etc.).



Space Rack Greasing Locations

7. TROUBLESHOOTING AND REPAIR

7. TROUBLESHOOTING AND REPAIR

7.1 Items To Be Checked Before Repair

When there is a user request for repair, check whether the printer can be fixed by the troubleshooting procedure described in the User's Manual.

If possible, ask the user about the conditions that caused the error and make a record of the answer.

Before troubleshooting, operate the printer under the same conditions as at the time of error and see whether the error can be reproduced. If the error cannot be reproduced, run a print test and proceed with troubleshooting.

7.2 Finding the Cause of Error

First check the error condition against table 7-1. Then follow instructions in 7-3. Troubleshooting, to find the actual cause of error.

Read the precautions in 4-1 before repairing.

Figure 7-1 shows the connector locations and pin numbers. Table 7-2 shows the pin signal names. Figure 7-2 shows the INDU and SLSX board checkpoints.

Table 7-1. Error Conditions

Error Type	Description	Item
During POWER ON	The carriage does not move.	①
	The carriage does not move and the POWER lamp is lit.	②
	Carriage moves abnormally (runaway, vibration, or incomplete homing) and POWER lamp is lit.	③
	Homing operation is normal, but indicators are abnormal.	④
	Fuse (F1) on the power supply board (SLPB) is blown.	⑤
	Fuse (F1) on the power supply board (INDU) is blown.	⑥
During data receive or print	Neither spacing nor printing is performed and POWER and SELECT lamps are lit.	⑦
	Spacing is normal, but does not print.	⑧
	Printing stops.	⑨
	Wrong characters printed or some characters not printed.	⑩
	Some dots not printed.	⑪
	Print is too light.	⑫
	Line feed not performed.	⑬
	Fuse (F1) on power supply board is blown.	⑭
	Switch on the operation panel does not work. (Carriage moves to home at power on.)	⑮
	Paper does not feed to print position (SASF function).	⑯









Figure 7-1. Connector Locations and Numbers of Pins

Table 7-2. Pin Numbers and Signal Names

Name	Signal Name	Connection								Coil Resistance	Figure
		A	B	C	D	E	F	G	H		
SP MOTOR	V	17		15	15					Approx. 21Ω	
	U	16		14	14						
	W	18		16	16						
	φA	22		20	20						
	φB	21		19	19						
PRINT HEAD	#1	14		13	13	14	14			Approx. 20Ω	
	#2	13		12	12	13	13				
	#3	1		1	1	1	1				
	#4	12		11	11	12	12				
	#5	2		2	2	2	2				
	#6	11		10	10	11	11				
	#7	3		3	3	3	3				
	#8	10		9	9	10	10				
	#9	4		4	4	4	4				
	Common	5,6,7		5,6	5,6	5,6,7	5,6,7				
	HEAD ALM	8		7	7	8	8				
	0V	9		8	8	9	9				
LF MOTOR	φ1	38	3							Approx. 70Ω	
	φ3	40	1								
	Common	39	2								
	φ2	37	4								
	φ4	35	6								
	Common	36	5								
OPERATION PANEL	SW SEL	31						7			
	SW 1	30						6			
	SW 2	28						4			
	SW 3	27						3			
	LAMP SEL	34						10			
	+5 V	32						8			
	0 V	29						5			
SWITCH	SASF	24									
	0V	20									
CN4	Approx. AC 7.6 V								2-5		
	Approx. AC 25.8 V								1-6		
	Approx. AC 10 V								3-4		

• INDU-Printed-Circuit Board



• SLSX-Printed-Circuit Board






Figure 7-2. Check points for Printed Circuit Boards

7.3 Troubleshooting

1 Power is on, but carriage does not move.



2**The Power LED lights when power is turned on, but the carriage does not move.**

Note: Be careful not to damage the copper foil on the connection board when measuring the resistance.

2-1

- Is the voltage difference between pins 1 and 6 of CN4 28.5 VAC with CN4 disconnected?

YES

NO

- Replace the transformer.

- Replace the INDU board.

2-2

- Is the cord clamp of connection ㉔ firmly attached?

YES

NO

- Check that the contact pressure rubber is firmly inserted.

- Is the ribbon feed assembly attached correctly?

YES

NO

- Check that the contact pressure rubber is firmly inserted.

- Are the screws on the connection board (SLBP) tight?

YES

NO

- Match the assembly to the board and tighten the screws.

- Is carriage cable broken?

NO

YES

- Replace the carriage cable (see 4.3.13).

- Remove the ribbon cassette and ribbon feed gear assembly. Check the resistance of space motor at connection ㉕ (see Figure 7-1).

- Is the resistance approximately 21 ohms?

YES

NO

- Replace the space motor assembly (see 4.3.11).


- Verify that the contacts of connection ㉔ are not damaged or worn.

3

Carriage movement is abnormal (runaway, vibration, incomplete homing) when the power is turned on.

• Runaway?
NO
YES
• Replace the INDU board.

• Vibration
YES
NO
• Is +30 V output?
YES
NO
• to step (2-1)
• to step C



• Are phase A, B signals output to Q4-79, 80?
YES
NO

A • Is the cord clamp of connection © firmly attached?
YES
NO
• to step B

• Is the ribbon feed assembly attached correctly?
YES
NO
B • Reassemble.

• Is connection board (SLBP) broken?
NO
YES
• Replace the connection board (see 4.3.9).

• Is carriage cable broken?
NO
YES
• Replace the carriage cable (see 4.3.13).

• Replace the space motor assembly (see 4.3.11).

C • Replace the INDU board.

• Is printer normal?

YES
NO
• Is the carriage easily moved by hand when the power is off?


YES
NO
• to step (2-a)

• to step A

• END

4

Homing operation is normal, but the indicators (LED1 to LED9) are abnormal when power is turned on.



4-1

• Is SELECT LED (LED1) lit?

NO

YES

• to step 4-2

• Is paper installed?

YES

NO

• Install paper.

• Is the printer in SELECT state?

YES

NO

• Press the SELECT switch (SW4).

• Is the SLSX board Q2-3 at H level and Q3-6 at L level?

YES

NO

• Replace the INDU board.

• Is +5 V applied to the anode of each LED?

YES

NO

• Correct connections at Ⓐ and Ⓒ.

• Replace the SLSX board.

4-2

- Is the 10 pitch LED (LED4) lit?

YES

NO

- Is the SLSX board Q2-5 at H level and Q3-2 at L level?

NO

YES

- Is +5 V applied to the anode of SLSX board LED?

YES

NO

- Correct connections at Ⓐ and Ⓒ.

- Replace the INDU board.

- Replace the INDU board.

- Is the UTILITY LED (LED8) lit?

YES

NO

- Is the SLSX board Q2-12 at H level and Q3-10 at L level?

NO

YES

- Is +5V applied to the anode of SLSX board LED?

YES

NO

- Correct connections at Ⓐ and Ⓒ.

- END

- Replace the INDU board.

5

Fuse F1 on power supply board (SLPB) blows when power is turned on.

- Is the fuse properly rated?

YES

NO

- Replace the fuse with properly rated fuse.

- Remove connector CN4 and turn on the power.

- Does the fuse blow again?

YES

NO

- Replace the INDU board.

- Replace the SLPB board and turn on the power.

- Does the fuse blow again?

YES

NO

- Normal operation.

- Replace the transformer.

6

Fuse F1 on the control board (INDU) blows when power is turned on.

- Is the fuse properly rated (1.5 A)?

YES

NO



- Replace the fuse with properly rated fuse.

- Replace the INDU board.

7

Neither spacing nor printing performed while receiving data.

- Verify that data is being sent to the printer.
- Is SELECT LED (LED1) lit?

YES

NO

- to step 4-1

- Are the signal levels at CN1 as shown in the table below with the interface cable removed?

Signal Level	
Pin 10	H
Pin 11	L
Pin 12	L
Pin 13	H
Pin 32	H

NO

YES

- Are parallel data signals (pins 2 to 9) and STB (pin 1) received with the cable connected?

YES

NO

- Is the interface cable connected correctly?

YES

NO

- Correct the interface cable connection.

- Replace the interface cable.

- Is self-test possible? (Perform with the interface cable removed.)

YES

NO

- Replace the INDU board.

- Replace the INDU board.

- Replace the INDU board.

8**Spacing is normal, but nothing is printed while receiving data.**

- Does TR10 on INDU board alternate between ON and OFF?

YES

NO

- Replace the INDU board.
- to step E

- E
- Replace the print head.

- Is printer operation normal?

YES

NO

8-a

- Turn off the power, remove the INDU board, and check the resistance between pins 5, 6, 7 and 1, 2, 3, 4, 10, 11, 12, 13, 14 at CN3 (connection board side) of connection **A**. (See table 7-2.)(Note)

- Is the resistance approximately 20 ohms?

YES

NO

- Is the cord clamp of connection **C** firmly attached?

YES

NO

- to step F

- Is the ribbon feed assembly correctly attached?

YES

NO

- F • Attach correctly.

- Is the connection board broken?

NO

YES

- Replace the connection board (see 4.3.9).

- Is the carriage cable broken?

NO

YES

- Replace the carriage cable (see 4.3.13).

- Is the print head connector deformed?

NO

YES

- Replace the connector.

- Verify that contacts at connections **C**, **D**, **E**, and **F**, are not damaged or worn.

- Replace the INDU board.

- END

• **Note:** Be careful not to damage the copper foil on the connection board when measuring the resistance.

9

Printing stops due to an ALARM while receiving data and printing

- Is the ALARM lamp (LED2) lit?
YES
↓
• Is the SELECT LED flickering?
YES
↓
• Is paper installed correctly?
YES
↓
• Turn off the power and manually move the carriage.
• Does the carriage move smoothly?
YES
↓
• Is homing performed properly?
NO
↓
• Check items ① to ③.
- NO
• Wait until the print head cools.
- NO
• Paper near end. Refill paper.
- NO
• Install paper correctly.
- NO
• to step ②-a
- YES
• Replace the space motor or the INDU board.

10

Wrong characters are printed or some characters are missing

- Is interface cable connected properly?

YES

NO

- Connect cable properly.

- Does self-test print normally?

YES

NO

- Replace the INDU board.

- Is the bit length set properly?

YES

NO

- Set the data bit length properly.

- Are data signals 1 to 8 input normally from host to CN1 pins 2 to 9?

YES

NO

- Replace the interface cable.

- Replace the INDU board.

11

Some dots are missing

- Remove the print head.

- Is any pin broken?

NO

YES

- Replace the print head.

- Check the resistance of print head coil at connection ⑥. (See table 7-2.)

- Is the resistance approximately 20 ohms?

YES

NO


- Replace the print head.

- to step

8-a

12

Print is light



13**Line feed is not performed**

- Is paper installed correctly?

YES

NO

- Install paper correctly.

(When single sheet is used the friction lever must be set to closed position.)

- Is the platen unusually hard to turn manually with the power off?

NO

YES

- Adjust the paper feed mechanism. (Check for paper jam and damaged parts.)

- Turn off the power, remove the INDU board, and check the resistance between pins 35 and 36, 36 and 37, 38 and 39, and 39 and 40 at CN3 (connection board side) of connection ①. (See table 7-2.) (Note)

- Is the resistance approximately 70 ohms?

YES

NO

- Is connection ② correct?

YES

NO

- Verify that the LF motor position is correct and the contacts are not bent.

- Is the pattern of connection board broken?

NO

YES

- Replace the connection board (see 4.3.9).

- Replace the LF motor (see 4.3.8).

- Replace the INDU board.

- Is printer operation normal?

YES

NO

- Replace the LF motor (see 4.3.8).

- END

• **Note:** Be careful not to damage the copper foil on the connection board when measuring the resistance.

14**Fuse F1 on power supply board blows while receiving data and printing**

- Is the fuse properly rated?

YES

NO

- Replace with properly rated fuse.

- Turn off the power and check the print head coil, SP motor, and LF motor resistance. (See table 7-2.)

- Is the print head resistance approximately 20 ohms?

YES

NO

- Replace the print head. Connect connections (A), (C), (D), (E), and (F) properly.

- Is the SP motor resistance approximately 21 ohms?

YES

NO

- Replace the SP motor. Connect connections (A), (C), and (D) properly.

- Is the LF motor resistance approximately 70 ohms?

YES

NO

- Replace the LF motor. Connect connections (A) and (B) properly.

- Replace the INDU board.

15

Switch on the operation panel does not work (Carriage returns to home position when power is turned on)

- Is signal input to Q4 pins 49 to 52 when the switch is pressed?

NO

YES

- Replace the INDU board.

- Are connections ① and ② proper?

YES

NO

- Correct the connections.

- Replace the SLSX board.

16**Paper not fed properly (SASF.function)**

- Turn off the power, remove the INDU board, open the bail arm, and check the resistance between pins 20 and 24 at connection ①.
- Is the resistance 0 ohms?
NO YES
↓
 - Replace the INDU board.
- Is the connection board broken?
NO YES
↓
 - Replace the connection board (see 4.3.9).
- Is the switch broken?
NO YES
↓
 - Replace the switch assembly (see 4.3.21).
- Replace the INDU board.

APPENDIX A

PCB LAYOUT




APPENDIX A PCB LAYOUT


— PCB List —


- (1) Circuit board, INDU (Main Controller)
- (2) Circuit board, SLSX (Operator Panel)
- (3) Circuit board, SLBP
- (4) Circuit board, SLHI (Option)

INDU-Printed-Circuit Board




• SLSX-Printed-Circuit Board





SLBP-Circuit Board



SLHI-Circuit Board









APPENDIX B







CIRCUIT SYMBOLS AND CIRCUIT DIAGRAMS


APPENDIX B CIRCUIT SYMBOLS AND CIRCUIT DIAGRAMS

Table 7-1 shows the symbols used in the circuit diagrams. Figure 9-1 is the circuit diagram.

Table 9-1 Table of Symbols

Symbol	Mark	Description
	Q	SN74LS05 inverter (open collector)
	Q	SN7406 inverter (open collector)
	OSC	Ceramic oscillator
	TR	Transistor
	SCR	Thyristor
	D	Diode
	D	Zener diode
	D	Light-emitting diode
	REG	Regulator

Symbol	Mark	Description
	C	Capacitor
	C	Electrolytic capacitor
	R	Resistor
	SW	Switch
	S	Jumper wire or plug
	CN	Connector (terminal)
 (Reference)		Means a single part.
	FG	Frame ground
		Dot head (element)
	L	Coil

Symbol	Mark	Description
	Q	339 Comparator
	THERMISTOR	Thermistor
	SG	Signal ground
	TF	Transformer
		Photo sensor
	F	Fuse

APPENDIX C

SPARE PARTS LIST

APPENDIX C SPARE PARTS LIST

Printer Unit	Figure 10-1
Printer Mechanism	Figure 10-2
Pin Tractor Unit	Figure 10-3
INDU-Printed-Circuit Board	Figure 10-4
SLPB Printed-Circuit Board	Figure 10-5




Figure 10-1. Printer Unit

Table 10-1. Printer Unit

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
1	2PB4017-3037P4	Lower cover	53506204	1	
2	4PB4025-1137P1	Rubber foot	53452701	4	
3	4PP4025-1152P1	Washer	50512101	4	
5	3PP4050-2174G3	Upper cover	53506303	1	
6	4PB4025-1123P10	DIP switch access cover	53447310	1	
7	3PA4017-3044P10	Access cover	53467410	1	
7	2PB4017-3048P7	Access cover (tractor)		1	Option
8	3PB4043-2156P7	Platen knob	53459807	1	
9	4PB4017-3046P9	Connector cover	53469209	1	
11	4YA4025-1401G2	Print head		1	
12	3YS4011-1265P1	AC cord		1	220/240V
13	3PA4025-2633G1	Pin tractor assembly		1	Option
14	2PB4025-1130P1	Acoustic cover	53450001	1	Option
15	2PA4017-3378G4	Paper separator	53459303	1	
16	3YX4025-1010G4	Printer mechanism		1	
17	4YA4050-2155G1	SLSX printed-circuit board	55035601	1	
18	4YA4050-2881G3	INDU printed-circuit board (with EP ROM)	N/A	1	(IBM)
18	4YA4050-2881G11	INDU printed-circuit board (for maintenance, without ROM)	N/A	1	
19	3YX4021-1032G1	AC transformer assembly	55029501	1	220/240 V
20	4PP4017-3038P1	Earth spring	50922701	1	
21	4PP4016-5904P4	Connector cover	53469209	1	





Figure 10-2. Printer Mechanism

Table 10-2. Printer Mechanism

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
1	1PP4025-1011P1	Base frame	53322301	1	
2	4PA4025-1012G1	Platen assembly	50210801	1	
3	3PA4025-1027G1	Paper chute assembly	50039101	1	
5	3PA4025-1032G1	Bottom paper guide assembly	50211401	1	
6	4PP4025-1038P1	Near-end bracket	53050601	1	
7	4PB4025-1039P1	Near-end lever	53050701	1	
8	4PB4025-1040P1	Bottom near-end lever	53051701	1	
9	4PP4025-1118G1	Carriage roller	53322501	1	
10	4PP4025-1048P1	Head clamp	50702901	1	
11	2PU4007-1065P1	Carriage cable	56613701	1	
12	4PA4025-1075G1	Ribbon feed gear assembly	50036501	1	
13	3PB4025-1116P1	Connector	56718601	1	
14	4PB4025-1088P1	Slider	51001401	1	
15	4PP4025-1114P1	Contact pressure rubber	53453001	1	
16	4PP4025-1182P1	Cable clamp	50703101	1	
17	4YX4025-1800G1	Space motor assembly	56404101	1	
18	4PB4025-1089P1	Carriage shaft	51109101	1	
19	4PB4025-1090P1	Main shaft screw	50310001	2	
20	3PA4025-2102G1	Indicator bar assembly	55035301	1	
22	4PB4025-1097P1	Pressure roller spring (R)	50907302	1	
23	4PB4025-1139P1	Pressure roller spring (L)	50907301	1	
24	4PP4025-1099P1	Contact rubber	53452901	1	
25	4PB4025-1100P1	Cord clamp	50702801	1	
26	3PP4025-1103P1	Circuit support		1	
27	2PU4003-5723P1	SLBP pnted-circuit board	55017801	1	
28	4PB4025-1105P1	LF motor	56504201	1	
29	4PB4025-1106P1	Tension spring	50907201	1	
30	4PB4025-1107P1	Release post	50605101	1	


Table 10-2. Printer Mechanism (Con'd)

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
31	4PB4025-1108P1	Release link (front)	51302401	1	
32	4PB4025-1109P1	Release link (rear)	51302501	1	
33	4PB4025-1110P1	Release link	51302601	1	
34	4PB4025-1113P1	Paper lock release lever	53448401	1	
35	4PB4025-1115P1	Stopper rubber	53453101	2	
36	4PB4025-1159P1	Grommet	50512201	4	
37	3PB4025-1049P1	Space rack	53447401	1	
39	4PA4025-2617G1	Switch assembly	56208401	1	




No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	3PB4025-2667P1	Pin tractor (R) assembly	50052701	1	Option
2	3PB4025-2668P1	Pin tractor (L) assembly	50052801	1	Option

Figure 10-3. Pin Tractor Unit



No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	540A0220M1152	Fuse 1.5 A	56301710	1	
1	540A2057M2162	Fuse 1.6 A		1	for UK Products

Figure 10-4. INDU-Printed-Circuit Board



No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	540A2036M2102	Fuse 1.0 A	56301501	1	120 V
1	540A2044S2631	Fuse 0.63 A	56301601	1	220 V/240 V

Figure 10-5. SLPB-Printed-Circuit Board

OKI

ML280

Dot Matrix Printer

Part List




Figure 10-1. Printer Unit

Table 10-1. Printer Unit

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
1	2PB4017-3037P4	Lower cover	53506204	1	
2	4PB4025-1137P1	Rubber foot	53452701	4	
3	4PP4025-1152P1	Washer	50512101	4	
5	3PP4050-2174G3	Upper cover	53506303	1	
6	4PB4025-1123P10	DIP switch access cover	53447310	1	
7	3PA4017-3044P10	Access cover	53467410	1	
7	2PB4017-3048P7	Access cover (tractor)		1	Option
8	3PB4043-2156P7	Platen knob	53459807	1	
9	4PB4017-3046P9	Connector cover	53469209	1	
11	4YA4025-1401G2	Print head		1	
12	3YS4011-1265P1	AC cord		1	220/240V
13	3PA4025-2633G1	Pin tractor assembly		1	Option
14	2PB4025-1130P1	Acoustic cover	53450001	1	Option
15	2PA4017-3378G4	Paper separator	53459303	1	
16	3YX4025-1010G4	Printer mechanism		1	
17	4YA4050-2155G1	SLSX printed-circuit board	55035601	1	
18	4YA4050-2881G3	INDU printed-circuit board (with EP ROM)	N/A	1	(IBM)
18	4YA4050-2881G11	INDU printed-circuit board (for maintenance, without ROM)	N/A	1	
19	3YX4021-1032G1	AC transformer assembly	55029501	1	220/240 V
20	4PP4017-3038P1	Earth spring	50922701	1	
21	4PP4016-5904P4	Connector cover	53469209	1	





Figure 10-2. Printer Mechanism

Table 10-2. Printer Mechanism

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
1	1PP4025-1011P1	Base frame	53322301	1	
2	4PA4025-1012G1	Platen assembly	50210801	1	
3	3PA4025-1027G1	Paper chute assembly	50039101	1	
5	3PA4025-1032G1	Bottom paper guide assembly	50211401	1	
6	4PP4025-1038P1	Near-end bracket	53050601	1	
7	4PB4025-1039P1	Near-end lever	53050701	1	
8	4PB4025-1040P1	Bottom near-end lever	53051701	1	
9	4PP4025-1118G1	Carriage roller	53322501	1	
10	4PP4025-1048P1	Head clamp	50702901	1	
11	2PU4007-1065P1	Carriage cable	56613701	1	
12	4PA4025-1075G1	Ribbon feed gear assembly	50036501	1	
13	3PB4025-1116P1	Connector	56718601	1	
14	4PB4025-1088P1	Slider	51001401	1	
15	4PP4025-1114P1	Contact pressure rubber	53453001	1	
16	4PP4025-1182P1	Cable clamp	50703101	1	
17	4YX4025-1800G1	Space motor assembly	56404101	1	
18	4PB4025-1089P1	Carriage shaft	51109101	1	
19	4PB4025-1090P1	Main shaft screw	50310001	2	
20	3PA4025-2102G1	Indicator bar assembly	55035301	1	
22	4PB4025-1097P1	Pressure roller spring (R)	50907302	1	
23	4PB4025-1139P1	Pressure roller spring (L)	50907301	1	
24	4PP4025-1099P1	Contact rubber	53452901	1	
25	4PB4025-1100P1	Cord clamp	50702801	1	
26	3PP4025-1103P1	Circuit support		1	
27	2PU4003-5723P1	SLBP pnted-circuit board	55017801	1	
28	4PB4025-1105P1	LF motor	56504201	1	
29	4PB4025-1106P1	Tension spring	50907201	1	
30	4PB4025-1107P1	Release post	50605101	1	


Table 10-2. Printer Mechanism (Con'd)

No.	Part No.	Description	ODA Part No.	Q'ty	Remarks
31	4PB4025-1108P1	Release link (front)	51302401	1	
32	4PB4025-1109P1	Release link (rear)	51302501	1	
33	4PB4025-1110P1	Release link	51302601	1	
34	4PB4025-1113P1	Paper lock release lever	53448401	1	
35	4PB4025-1115P1	Stopper rubber	53453101	2	
36	4PB4025-1159P1	Grommet	50512201	4	
37	3PB4025-1049P1	Space rack	53447401	1	
39	4PA4025-2617G1	Switch assembly	56208401	1	




No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	3PB4025-2667P1	Pin tractor (R) assembly	50052701	1	Option
2	3PB4025-2668P1	Pin tractor (L) assembly	50052801	1	Option

Figure 10-3. Pin Tractor Unit



No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	540A0220M1152	Fuse 1.5 A	56301710	1	
1	540A2057M2162	Fuse 1.6 A		1	for UK Products

Figure 10-4. INDU-Printed-Circuit Board



No.	Part No.	Description	ODA Parts No.	Q'ty	Remarks
1	540A2036M2102	Fuse 1.0 A	56301501	1	120 V
1	540A2044S2631	Fuse 0.63 A	56301601	1	220 V/240 V

Figure 10-5. SLPB-Printed-Circuit Board

MICROLINE. 280
TROUBLESHOOTING MANUAL
With
COMPONENT PARTS LIST

PREFACE

This manual describes the component level troubleshooting and repair process for the ML280.

TROUBLESHOOTING MANUAL

CONTENTS

1. Outline	I-I
2. Tools	I-I
3. Troubleshooting Procedure	1-2
4. Troubleshooting Flowchart	1-3

1 Outline

General

This troubleshooting manual is designed to locate and repair problems on a component level for the INDU-printed-circuit boards and other printer components.

1.1 Remarks

This manual requires basic knowledge of electronic circuits.

- Use chip-dedicated soldering irons (such as **Ungar** soldering irons) since the printed-circuit boards of the **ML280** have heat-destructible components (chips, packages, etc.). (Soldering irons for flat packages are widely available.)
- Be careful not to break any wiring etched trace patterns on the printed-circuit boards while replacing components.


2 Tools

In addition to the tools listed in the printer's Maintenance manual, the following tools are required for repair of components on the printed-circuit boards:

. Extension cord (OKI Part No. 3YU5003-5010G1 or equivalent)

- | | |
|----------------------------------|--------------------------|
| • Oscilloscope | } commercially available |
| . Soldering iron (with fine tip) | |
| • Solder wick | |

3 Troubleshooting Procedure





Notes 1: Visually check the defective printed-circuit board before mounting it on the printer.

2: If the printer or the printed-circuit board is returned along with an error report, first check the reported failure.

4 Troubleshooting Flowchart

4.1 General Flowchart





Note: PITCH and MODE switches are valid during select and deselect states.

II

Local test printing

Turn the power switch on while LF switch is depressed.

Is rolling ASCII pattern printed normally?

Yes

Proceed to (III)

No

Neither spacing nor printing operation occurs.

Fault & cause

Proceed to

Switch circuit
paper end

(6-1)
Install
paper

The spacing operation is normal,
but the printing operation is
not performed.

Printhead drive
circuit

(8-1)

Some dots are not printed.

Printhead drive
circuit

(8-2)

Print is not dark enough.

Printhead drive
Ribbon

(8-3)

III

Data receiving

Power off connect interface cable.
Turn power on.

Is received data printed normally?

Yes

END

No

Is the serial interface board mounted?

Yes

Fault & Cause

Proceed to

Refer to the printer maintenance manual for serial interface board

No

Does not print at all

Interface circuit

9-1

Wrong characters are printed or some characters are not printed

Interface circuit

9-2


The printing operation stops

Interface circuit SP MOTOR spacing ALARM
Head temperature ALARM


9-3


4.2 Troubleshooting Flowchart

1. Fuse blow



Note: This step is required since parts are overloaded if power is repeatedly supplied with the defective driver parts.







2. Power supply circuit


2-1

AC circuit and transformer




2-2

DC +5 V, +8 V circuit




2-3


DC +30 V circuit



3. μ CPU circuit



Notes 1:




- 2: The level of each of the output signals should not be at half level (about 2 to 3 V).


4. SP motor drive circuit

4-1


Faulty homing operation



(When printing utility mode at 10CPI)




Note: The phase of the line-feed motor is adjusted when a space-homing is made at power on. Turn on the POWER switch while touching the platen knob. When you feel the platen knob rotate, the CPU circuit is normal.



5. Lamp circuit


5-1

Power Lamp does not light.





5-2


ALARM Lamp does not light




SELECT Lamp does not light.







6. Switch circuit




7. Line feed motor circuit

7-1

Does not perform line feed operation


Observe the following signals
 LFφ1 (Q4-74)
 LFφ2 (Q4-75)
 LFφ3 (Q4-76)
 LFφ4 (Q4-77)
 LFOVD (Q4-73)
 When LF is to be executed




• Check the resistance of the LF motor. Resistance should be about 70Ω.
 • Replace the LF Motor.
 • Check the connection circuit.

LF motor	Connector CN3	Pins	resistance.
	40	39-40	Approx. 70Ω
	39	39-38	Approx. 70Ω
	38	36-37	Approx. 70Ω
	37	36-35	Approx. 70Ω
	36	40-38	Approx. 140Ω
	35	37-35	Approx. 140Ω


LF Timing chart



8. Printhead drive circuit




Note: Measure the resistance of each printhead, it should be about 20Ω .




Common - 2ins	Pins 5,6,7	resistance
#3	1-5	} Approx. 20 Ω
#5	2-5	
#7	3-5	
#9	4-5	
#8	10-5	
#6	11-5	
#4	12-5	
#2	13-5	
#1	14-5	

Some dots are not printed.




Note: Measure the resistance of each printhead coil. It should be about 20 Ω.



Common - 2ins	Pins	resistance
#3	5,6,7	1-5
#5		2-5
#7		3-5
#9		4-5
#8		10-5
#6		11-5
#4		12-5
#2		13-5
#1		14-5

Approx 20 Ω

Print is not dark enough.



Head ON


Head 1 to 9

Q7-6 Threshold level

Q7-1

TR502-C


Head drive current





9. Interface (Receiving)


9-1


Does not print at all.




signal pins	Level
Busy CN1-11	L
ACK CN1-10	H
PE CN1-12	L
SELECT CN1-13	H
FAULT CN1-32	H







10. SASF operation



COMPONENT PARTS LIST

Drawing List

INDU-Printed Circuit Board	4YA4050-2881Gxxx	I-I
{ • INDU-Printed Circuit Board with ROM • INDU-Printed Circuit Board without ROM	4YA4050-2881G3 (IBM) 4YA4050-2881G11.....	1-5 1 - 1 3
SLSX-Printed Circuit Board	4YA4050-2155G1.....	1 - 2 1
SLPB-2, 3 Printed Circuit Board	3YU5003-5611G2/G3	1-25

ROM identification Chart by G No.

G No.	ROM-No.	ROM part No.	ROM Label	Application	Remarks
G003	08	4YR4067-7145G1	67-7145	For INDU	IBM




Figure 1 INDU-Printed Circuit Board (4YA4050-2881Gxxx) 1/2 (1/2)

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-1/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
1		ROM IC write specification	4YR4067-7145G1	1	OEL IBM
2					
3	D1,D7,D12-15	EM01Z/SM1XN02/DSM1D2 Rectifier diode	610A0003M0001	6	
4	D8-11	DSM1E1 Rectifier diode	610A0021M0093	4	
5	D6	DFA1A1 Rectifier diode	610A0221L0021	1	
6	D2,D3,D16, D506,D508, D512-D515, D517	MA151WK/N202K/2838 Signal diode (CP)	611A0003N0003	10	
7	D4	MA3075-M/RD7.5M-B2 Zener diode (CP)	613A0103M0152B	1	
8	D509,D510	MA3047-H Zener diode (CP)	613A0291M0102H	2	
9	D511	MA3100/RD10M-B Zener diode (CP)	613A0103M0182	1	
10	D507	RD22M-B3 Zener diode (CP)	613A0233M0262C	1	
11	D5,D501	MA3300/RD30M-B Zener diode (CP)	613A0103M0292	2	
12	D504,D505	MA152WK.OT Signal diode (CP)	611A0029N0003A	2	
13	D503	RD24M-B Zener diode (CP)	613A0233M0272	1	
14	D502	MA3200 Zener diode (CP)	613A0291M0252	1	
15	SCR	CR3CM-8 Gate thyristor OFF	620A0022M0006E	1	
16					
17	R610,R620, R623,R625	2125JPW Chip jumper (CP)	323A5003P0001	4	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-2/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
18	R606	RM73B2A180J RN resistor (CP)	323A5003J0180	1	
19	R27	M0R2B39ΩJ RS resistor	324A1121J0390	1	
20	R18,R562,R615	RM73B2A101J RN resistor (CP)	323A5003J0101	3	
21	R23,R24	RD1/2Y300ΩJ RD resistor	321A1431J0301	2	
22	R501	RM73B2A431J RN resistor (CP)	323A5003J0431	1	
23	R504,R548	RM73B2A511J RN resistor (CP)	323A5003J0511	2	
24	R17	RM73B2A561J RN resistor (CP)	323A5003J0561	1	
25	R16,R19,R522, R563,R564	RM73B2A102J RN resistor (CP)	323A5003J0102	5	
26	R53,R505,R523, R617,R618	RM73B2A122J RN resistor (CP)	323A5003J0122	5	
27	R547	RM73B2A182J RN resistor (CP)	323A5003J0182	1	
28	R26	RD1/2Y2KΩJ RD resistor	321A1431J0202	1	
29	R51,R52,R502, R537,R613	RM73B2A202J RN resistor (CP)	323A5003J0202	5	
30	R21	RM73B2A222F RN resistor (CP)	323A5003F0222	1	
31	R1,R8,R9,R50, R526,R530,R616	RM73B2A222J RN resistor (CP)	323A5003J0222	7	
32	R22,R535,R539	RM73B2A242F RN resistor (CP)	323A5003F0242	3	
33	R10-14,R516, R527,R528, R544, R566-R568, R571-578	RM73B2A332J RN resistor (CP)	323A5003J0332	20	
34	R524,R525, R534	RM73B2A472J RN resistor (CP)	323A5003J0472	3	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-3/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
35	R20,R518, R532,R553, R605,R607, R608,R609, R611	RM73B2A562J RN resistor (CP)	323A5003J0562	9	
36	R25	RD1/2Y6.2KΩJ RD resistor (CP)	321A1431J0622	1	
37	R550	RM73B2A682J RN resistor (CP)	323A5003J0682	1	
38	R2,R5,R503, R517, R519-R521, R529,R538, R545, R554-R561, R569,R570, R515,R594, R604,R614	RM73B2A103J RN resistor (CP)	323A5003J0103	24	
39	R536	RM73B2A153F RN resistor (CP)	323A5003F0153	1	
40	R514	RM73B2A203J RN resistor (CP)	323A5003J0203	1	
41	R612	RM73B2A513J RN resistor (CP)	323A5003J0513	1	
42	R543	RM73B2A683J RN resistor (CP)	323A5003J0683	1	
43					
44	R4,R15, R506-R513, R549	RM73B2A104J RN resistor (CP)	323A5003J0104	11	
45	R546	RM73B2A124F RN resistor (CP)	323A5003F0124	1	
46	R6	RM73B2A224J RN resistor (CP)	323A5003J0224	1	
47	R7	MSF1/2B0.51ΩJ RS resistor	324A1001J0518	1	
48	R28	FMRI-1.8ΩJ Fuse resistor	327A1002J0189	1	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-4/8)
4YA4050-2881G1

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
49					
50	C545	CC2012SL1H470J 50V CC capacitor (CP)	303A3007K0470	1	
51	C506	CC2012CH1H100D 50V CC capacitor (CP)	303A3007C0100	1	
52					
53	C511,C528, C538-C541, C601-C609	CC2012SL1H221J 50V CC capacitor (CP)	303A3007K0221	15	
54	C509	CC2012SL1H561J 50V CC capacitor (CP)	303A3007K0561	1	
55	C502,C503, C535	CK2012B1H102K 50V CK capacitor (CP)	303A6008K3102	3	
56	C505,C525, C529	CK2012B1H103K 50V CK capacitor (CP)	303A6008K3103	3	
57	C6,C507,C508, C516,C517, C519,C524, C527, C531-C534, C536, C542,C543, C544, C546-C549	CK2012F1H104Z 50V CK capacitor (CP)	303A6008Z3104	20	
58	C512	CK2012B1H472K 50V CK capacitor (CP)	303A6008K3472	1	
59					
60					
61	C9	CEUSM2A010 100V CE capacitor 1.0UF	304A1041A2109	1	
62	C3,C4	CEUSM1H100 50V CE capacitor 10UF	304A1041H1100	2	
63	C7	CEUSM1E470 25V CE capacitor 47UF	304A1041E1470	1	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-5/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
64	C11	CEUSM1A101 10V CE capacitor 100UF	304A1041A1101	1	
65	C10	16VBSN-8200 (M) 16V CE capacitor 8200UF	304A1037C9822	1	
66	C12	42VPSN-4700 (M) 42V CE capacitor 4700UF	304A1108G1472	1	
67	C5	CQMF92PP2A223G-FO CQ capacitor 0.022UF	306A4103G2223	1	
68	C8,C14,C15	TCK45F2E103ZYA 250V CK capacitor 10000PF	302A4027Z5103	3	
69	C2	CEUSM2A3R3 100V CE capacitor 3.3UF	304A1041A2339	1	
70					
71	Q7	NJM2901M/UPC339G2 BIP linear IC (SO)	720A0503N0007	1	
72	Q12	MSM80C154RS-1 MOS-CPU (ROM)	853A0134F0049	1	
73	Q4	MSM6990GS-V1K MOS digital IC (FP)	702A2024N0003	1	
74	Q3	74LS06FP BIP digital IC (SO)	700A0503N0006	1	
75	Q13	5128-20GS/5517CFL-20 MOS-S-RAM (SO)	804A0003N4302	1	
76					
77		DICF-28CS-E IC socket	245A1221P0280	1	
78					
79	F1	GHMF-125V1.5A Fuse	540A0220M1152	1	
80	L1	RSL1513N102K/OL1614 H coil	353A3040K0102	1	
81					

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-6/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
82	TR9, TR11	2SA1331/2SA1037K PNP-HF-TR (CP)	600A1003N0002	2	
83	TR1, TR503, TR505, TR507	A1344/UN2111/DTA114K PNP-HF-TR (CP)	600A1003N0003	4	
84					
85	TR14	2SB761/2SB858-B PNP-LF-TR	601A1203M0002	1	
86					
87	TR3	2SB1123 PNP-LF-TR (CP)	601A1032N0002	1	
88	TR4	2SB766A-Q/R PNP-LF-TR (CP)	601A1130M0001	1	
89	TR13, TR501, TR504, TR506, TR508	2SC3361/2SC2412K NPN-HF-TR (CP)	602A1003N0002	5	
90	TR502	2SC3361 NPN-HF-TR (CP)	602A1032N0002	1	
91					
92	TR12	2SC2713 NPN-HF-TR (CP)	602A1025N0050	1	
93	TR2, TR5-TR8	2SD1472 NPN-LF-TR (CP)	603A1121N0007	5	
94	TR10	2SB882 PNP-LF-TR	601A1132M0003	1	
95					
96	Q1, Q2	M54661P/LB1731 BIP-INF-IC	710A2003M0001	2	
97	MTDV	HA13412 BIP linear IC	720A4021E0004	1	
98	REG	LA5005 BIP linear IC	720A1033M0001	1	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-7/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
99					
100	SP4,SP5,SP6	IMSA9202B-1-03Z013GF PC connector	224A4082P0030	3	
101	SP11	IMSA9202B-1-06Z013GF PC connector	224A4082P0060	1	
102					
103	DIPSW	KSD08G DIP switch	206A1082P0800	1	
104					
105	CN1	57LE-40360-7300 (D53) Rectangular connector	220A1423P0361	1	
106	CN2	00-9072-230-101-883 PC connector	224A3376P0300	1	
107	CN3	PD40A2XO PC connector	224A1160P0400	1	
108	CN4	172681-6 PC connector	224A3462P0060	1	
109	CN5	TCS-7588-01-201 Round shape connector	221A1525P0081	1	
110					
111	OSC	FAR-C4SB16000000M12C Piezo-electric vibrator	381A2001B0005	1	
112					
113	PE	EE-SJ5-B Photocoupler	652A0127M0009	1	
114					
115		FP-213 Fuse holder	4LP-7142	2	
116	FB1-FB3	DSS306-OAFZ103N EMI filter	342A1009P3103	3	

INDU-Printed Circuit Board (With ROM) PCB REV. 4, REV. 4 (2/2-8/8)
4YA4050-2881G3

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
117	BF1,BF2	ZBF253D-01 Fuse filter	377A1115P1309	2	
118					
119		IMSA-9206H-GF PC connector	224A4080P0020	5	
120		Varnished cotton tube (Black) L=4	4PP4010-1002P004	3	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-1/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
1					
2					
3	D1,D7,D12-15	EM01Z/SM1XN02/DSM1D2 Rectifier diode	610A0003M0001	6	
4	D8-11	DSM1E1 Rectifier diode	610A0021M0093	4	
5	D6	DFA1A1 Rectifier diode	610A0221L0021	1	
6	D2,D3,D16, D506,D508, D512-D515, D517	MA151WK/N202K/2838 Signal diode (CP)	611A0003N0003	10	
7	D4	MA3075-M/RD7.5M-B2 Zener diode (CP)	613A0103M0152B	1	
8	D509,D510	MA3047-H Zener diode (CP)	613A0291M0102H	2	
9	D511	MA3100/RD10M-B Zener diode (CP)	613A0103M0182	1	
10	D507	RD22M-B3 Zener diode (CP)	613A0233M0262C	1	
11	D5,D501	MA3300/RD30M-B Zener diode (CP)	613A0103M0292	2	
12	D504,D505	MA152WK.OT Signal diode (CP)	611A0029N0003A	2	
13	D503	RD24M-B Zener diode (CP)	613A0233M0272	1	
14	D502	MA3200 Zener diode (CP)	613A0291M0252	1	
15	SCR	CR3CM-8 Gate thyristor OFF	620A0022M0006E	1	
16					
17	R610,R620, R623,R625	2125JPW Chip jumper (CP)	323A5003P0001	4	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-2/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
18	R606	RM73B2A180J RN resistor (CP)	323A5003J0180	1	
19	R27	MOR2B39ΩJ RS resistor	324A1121J0390	1	
20	R18,R562,R615	RM73B2A101J RN resistor (CP)	323A5003J0101	3	
21	R23,R24	RD1/2Y300ΩJ RD resistor	321A1431J0301	2	
22	R501	RM73B2A431J RN resistor (CP)	323A5003J0431	1	
23	R504,R548	RM73B2A511J RN resistor (CP)	323A5003J0511	2	
24	R17	RM73B2A561J RN resistor (CP)	323A5003J0561	1	
25	R16,R19,R522, R563,R564	RM73B2A102J RN resistor (CP)	323A5003J0102	5	
26	R53,R505, R523,R617, R618	RM73B2A122J RN resistor (CP)	323A5003J0122	5	
27	R547	RM73B2A182J RN resistor (CP)	323A5003J0182	1	
28	R26	RD1/2Y2KΩJ RD resistor	321A1431J0202	1	
29	R51,R52,R502, R537,R613	RM73B2A202J RN resistor (CP)	323A5003J0202	5	
30	R21	RM73B2A222F RN resistor (CP)	323A5003F0222	1	
31	R1,R8,R9,R50, R526,R530, R616	RM73B2A222J RN resistor (CP)	323A5003J0222	7	
32	R22,R535,R539	RM73B2A242F RN resistor (CP)	323A5003F0242	3	
33	R10-14,R516, R527,R528, R544, R566-R568, R571-R578	RM73B2A332J RN resistor (CP)	323A5003J0332	20	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-3/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
34	R524,R525, R534	RM73B2A472J RN resistor (CP)	323A5003J0472	3	
35	R20,R518, R532,R553, R605,R607, R608,R609, R611	RM73B2A562J RN resistor (CP)	323A5003J0562	9	
36	R25	RD1/2Y6.2KΩJ RD resistor	321A1431J0622	1	
37	R550	RM73B2A682J RN resistor (CP)	323A5003J0682	1	
38	R2,R5,R503, R517, R519-R521, R529,R538, R545, R554-R561, R569,R570, R515,R594, R604,R614	RM73B2A103J RN resistor (CP)	323A5003J0103	24	
39	R536	RM73B2A153F RN resistor (CP)	323A5003F0153	1	
40	R514	RM73B2A203J RN resistor (CP)	323A5003J0203	1	
41	R612	RM73B2A513J RN resistor (CP)	323A5003J0513	1	
42	R543	RM73B2A683J RN resistor (CP)	323A5003J0683	1	
43					
44	R4,R15, R506-R513, R549	RM73B2A104J RN resistor (CP)	323A5003J0104	11	
45	R546	RM73B2A124F RN resistor (CP)	323A5003F0124	1	
46	R6	RM73B2A224J RN resistor (CP)	323A5003J0224	1	
47	R7	MSF1/2B0.51ΩJ RS resistor	324A1001J0518	1	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-4/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
48	R28	FMR1-1.8ΩJ Fuse resistor	327A1002J0189	1	
49					
50	C545	CC2012SL1H470J 50V CC capacitor (CP)	303A3007K0470	1	
51	C506	CC2012CH1H100D 50V CC capacitor (CP)	303A3007C0100	1	
52					
53	C511,C528, C538-C541, C601-C609	CC2012SL1H221J 50V CC capacitor (CP)	303A3007K0221	15	
54	C509	CC2012SL1H561J 50V CC capacitor (CP)	303A3007K0561	1	
55	C502,C503, C535	CK2012B1H102K 50V CK capacitor (CP)	303A6008K3102	3	
56	C505,C525, C529	CK2012B1H103K 50V CK capacitor (CP)	303A6008K3103	3	
57	C6,C507,C508, C516,C517, C519,C524, C527, C531-C534, C536,C542, C543,C544, C546-C549	CK2012F1H104Z 50V CK capacitor (CP)	303A6008Z3104	20	
58	C512	CK2012B1H472K 50V CK capacitor (CP)	303A6008K3472	1	
59					
60					
61	C9	CEUSM2A010 100V CE capacitor 1.0UF	304A1041A2109	1	
62	C3,C4	CEUSM1H100 50V CE capacitor 10UF	304A1041H1100	2	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-5/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
63	C7	CEUSM1E470 25V CE capacitor 47UF	304A1041E1470	1	
64	C11	CEUSM1A101 10V CE capacitor 100UF	304A1041A1101	1	
65	C10	16VBSN-8200 (M) 16V CE capacitor 8200UF	304A1037C9822	1	
66	C12	42VPSN-4700 (M) 42V CE capacitor 4700UF	304A1108G1472	1	
67	C5	CQMF92PP2A223G-FO CQ capacitor 0.022UF	306A4103G2223	1	
68	C8,C14,C15	TCK45F2E103ZYA 250V CK capacitor 10000PF	302A4027Z5103	3	
69	C2	CEUSM2A3R3 100V CE capacitor 3.3UF	304A1041A2339	1	
70					
71	Q7	NJM2901M/UPC339G2 BIP linear IC (SO)	720A0503N0007	1	
72	Q12	MSM80C154RS-1 MOS-CPU (ROM)	853A0134F0049	1	
73	Q4	MSM6990GS-V1K MOS digital IC (FP)	702A2024N0003	1	
74	Q3	74LS06FP BIP digital IC (SO)	700A0503N0006	1	
75	Q13	5128-20GS/5517CFL-20 MOS-S-RAM (SO)	804A0003N4302	1	
76					
77		DICF-28CS-E IC socket	245A1221P0280	1	
78					
79	F1	GHMF-125V1.5A Fuse	540A0220M1152	1	
80	L1	RSL1513N102K/OL1614 H coil	353A3040K0102	1	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-6/8)
4YA4050-2881G11


No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
81					
82	TR9, TR11	2SA1331/2SA1037K PNP-HF-TR (CP)	600A1003N0002	2	
83	TR1, TR503, TR505, TR507	A1344/UN2111/DTA114K PNP-HF-TR (CP)	600A1003N0003	4	
84					
85	TR14	2SB761/2SB858-B PNP-LF-TR	601A1203M0002	1	
86					
87	TR3	2SB1123 PNP-LF-TR (CP)	601A1032N0002	1	
88	TR4	2SB766A-Q/R PNP-LF-TR (CP)	601A1130M0001	1	
89	TR13, TR501, TR504, TR506, TR508	2SC3361/2SC2412K NPN-HF-TR (CP)	602A1003N0002	5	
90	TR502	2SC3361 NPN-HF-TR (CP)	602A1032N0002	1	
91					
92	TR12	2SC2713 NPN-HF-TR (CP)	602A1025N0050	1	
93	TR2, TR5-TR8	2SD1472 NPN-LF-TR (CP)	603A1121N0007	5	
94	TR10	2SB882 PNP-LF-TR	601A1132M0003	1	
95					
96	Q1, Q2	M54661P/LB1731 BIP-INF-IC	710A2003M0001	2	
97	MTDV	HA13412 BIP linear IC	720A4021E0004	1	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-7/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
98	REG	LA5005 BIP linear IC	720A1033M0001	1	
99					
100	SP4,SP5,SP6	IMSA9202B-1-03Z013GF PC connector	224A4082P0030	3	
101	SP11	IMSA9202B-1-06Z013GF PC connector	224A4082P0060	1	
102					
103	DIPSW	KSD08G DIP switch	206A1082P0800	1	
104					
105	CN1	57LE-40360-7300 (D53) Rectangular connector	220A1423P0361	1	
106	CN2	00-9072-230-101-883 PC connector	224A3376P0300	1	
107	CN3	PD40A2X0 PC connector	224A1160P0400	1	
108	CN4	172681-6 PC connector	224A3462P0060	1	
109	CN5	TCS7588-01-201 Round shape connector	221A1525P0081	1	
110					
111	OSC	FAR-C4SB16000000M12C Piezo-electric vibrator	381A2001B0005	1	
112					
113	PE	EE-SJ5-B Photocoupler	652A0127M0009	1	
114					
115		FP-213 Fuse holder	4LP-7142	2	

INDU-Printed Circuit Board (Without ROM) PCB REV. 4, REV. 4 (2/2-8/8)
4YA4050-2881G11

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
116	FB1-FB3	DSS306-OAFZ103N EMI filter	342A1009P3103	3	
117	BF1,BF2	ZBF253D-01 Fuse filter	377A1115P1309	2	
118					
119		IMSA-9206H-GF PC connector	224A4080P0020	5	
120		Varnished cotton tube (Black) L=4	4PP4010-1002P004	3	



PCB REV.	REV. NO.
3	3

Figure 2 SLSX-Printed Circuit Board (4YA4050-2155G1) 1/2

SLSX-Printed Circuit Board PCB REV. 3, REV. 3 (2/2-1/3)
4YA4050-2155G1


No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
1					
2					
3					
4	R10,12,15,16	RD1/4Y220ΩJ RD resistor	321A1421J0221	4	
5	R11	RD1/4Y430ΩJ RD resistor	321A1421J0431	1	
6	R9	RD1/4Y1KΩJ RD resistor	321A1421J0102	1	
7	R1-7,14	RD1/4Y5.6KΩJ RD resistor	321A1421J0562	8	
8	R8,13	RD1/4Y10KΩJ RD resistor	321A1421J0103	2	
9					
10	C3	CK92C1H471MS CK capacitor	303A4115M3471	1	
11	C4	CK92F1H104ZY CK capacitor	303A0420Z3104	1	
12	C1	TCK45F2E103ZYA CK capacitor	302A4027Z5103	1	
13	C2,5	16MS5-10M CE capacitor	304A1046C1100	2	
14					
15	Q3	74LS06P BIP digital IC	700A0503M0006	1	
16	Q1	74LS157P BIP digital IC	700A0503M0157	1	
17	Q2	MSM4015BRS SR memory IC	820A5024F2031	1	
18					

SLSX-Printed Circuit Board PCB REV. 3, REV. 3 (2/2-2/3)
4YA4050-2155G1

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
19	TR1,2,3	DTC114ES Transistor	602A1035M0007	3	
20					
21	LED1,3-9	SLP-265B LED	650A0344M0003	8	
22	LED2	SLP-165B LED	650A0144M0004	1	
23					
24					
25	SW1-6	SOA-113HS Push button switch	205A1162P1001	6	
26					
27	CN1	FH1-10SA-2.54DSA PC connector	224A3091P0100	1	
28					
29					
30					
31	S1	U-shape jumper wire 0.65 P=2.5	5KH-31036-25	1	
32	S2	U-shape jumper wire 0.65 P=7.5	5KH-31036-75	1	
33					
34		LED support bracket	4PP4050-2161P001	1	
35		LED support bracket	4PP4050-2162P001	2	
36		Operation board barrier	4PP4050-2187P001	2	


SLSX-Printed Circuit Board PCB REV. 3, REV. 3 (2/2-3/3)
4YA4050-2155G1

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
37	JW	SMRJ-B-10×48 Jumper	238A1064P0003	1	



PCB REV.	REV. NO.
6	5

Figure 3 SLPB-2 Printed Circuit Board (3YU5003-5611G2) 1/2 (Version 3)



PCB REV.	REV. NO.
6	5

SLPB-3 Printed Circuit Board (3YU5003-5611G3) 1/2 (Version 3)

SLPB-2, 3 Printed Circuit Board PCB REV. 6, REV. 5 (2/2-1/2)
3YU5003-5611Gx

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
1	C1,C2	Ceramic capacitor 400V 4700PF	302A4035Z6472	2	
2					
3					
4	L1	SC coil	4LP-45481	1	
5					
6	F1	Fuse 1A	540A2036M2102	1	For G2
		Fuse 0.63A	540A2044S2631	2	For G3
7		Fuse holder	4LP-7142	2	
8					
9	SW1	EST-15747V Toggle switch	200A3113P2000	1	
10					
11		Socket contact	224A7172P0001	2	
12					
13					
14					
15		Inlet	4LP-7144	1	
16					
18		FG lead wire	4YS4011-1507G003	1	

SLPB-2, 3 Printed Circuit Board PCB REV. 6, REV. 5 (2/2-2/2)
3YU5003-5611Gx

No.	Symbol	Type/Name	Part No.	Q'ty	Remarks
19		33/0.18 Heat-shrinkable PVC Wire (Black)	LY-4658-7-BK	1	
20		33/0.18 Heat-shrinkable PVC Wire (White)	LY-4658-7-WE	1	
21		33/0.18 Heat-shrinkable PVC Wire (Green/Yellow)	LY-4658-7-GYW	1	
22					
23					
24		Fuse Name Plate (220V)	4PB4012-5182P001	1	For G3